



# **Dust Networks**

# SmartMesh<sup>®</sup> LTP5900 Integration Guide





# **Table of Contents**

About This Guide	. 3
Audience	3
Related Documents	3
Conventions and Terminology	3
Revision History	3
Design Guidelines	. 4
Schematic Design	4
Supply Design	4
EMI Considerations	4
Antenna ESD Considerations	5
Voltage Supervision and Reset	
Design for Manufacture	5

# **List of Figures**

Figure 1	Programming Header Example Schematic
----------	--------------------------------------

# **List of Tables**





# **About This Guide**

This document provides the design guidelines essential for incorporating a LTP5900. The document covers design, layout, EMI, some device configuration and manufacturing considerations.

#### **Audience**

This document is intended for system developers, hardware designers, and layout engineers.

## **Related Documents**

The following related documents are available:

<u>LTP5900-WHM SmartMesh WirelessHART Mote PCB Module</u> <u>LTP5900 Module RF Shield</u> <u>Eterna Serial Programmer Guide</u> <u>ETERNA1 User Guide</u>

## **Conventions and Terminology**

This guide uses the following text conventions:

- Computer type indicates information that you enter, such as a URL.
- Bold type indicates buttons, fields, and menu commands.
- *Italic type* is used to introduce a new term.
- **Note:** Notes provide more detailed information about concepts.
- Caution: Cautions advise about actions that might result in loss of data.
- **Warning:** Warnings advise about actions that might cause physical harm to the hardware or your person.

## **Revision History**

Revision	Date	Description
040-0111 rev 1	2/14/2012	Initial Release
040-0111 rev 2	7/19/2012	Corrected part number references
040-0111 rev 3	10/24/2013	Update doc number and references





# **Design Guidelines**

# **Schematic Design**

The LTP5900 includes sufficient power supply filtering and decoupling capacitance such that additional filtering should not be necessary for most battery-powered designs. Care must be taken to avoid large transient voltages on the supply as the LTP5900 steps up its current consumption (see the section on Supply Design below).

# **Supply Design**

Due to the heavy duty cycling, the LTP5900's current consumption can change substantially over a short period. This does not represent an issue for systems with supplies having low source impedance (less than 5 0hms). Regulated supplies, however, may have difficulty in the sudden changes in current consumption (more than an order of magnitude in less than 1  $\mu$ s), resulting in transient voltages on the supply co-incident with the higher current consumption of the radio operation. To ensure proper operation of the radio, a supply should be able to ramp from 250  $\mu$ A to 10 mA in less than 1  $\mu$ s without generating a transient greater than 200 mV. For systems with regulated supplies, consultation with Linear Technology Applications Engineering is strongly recommended.

## **EMI Considerations**

Like all radio devices, the radio incorporated in the LTP5900 can be sensitive to EMI. The LTP5900 is designed with an RF Shield sufficient to allow the radio to operate in most environments. In environments with high AC and DC magnetic fields, the use of a mu-metal shield is recommended instead. Therefore, a custom design based upon the LTP5900 would be needed. Further, RF shield thickness is application-dependent. Consult Linear Technology Application Engineering for support.

In designs that include switching power supply(ies) resulting in switching currents through an inductor, it is essential to keep the inductor(s) a minimum of 1.25" from the LTP5900 radio, preferably on the opposite side of a PCB, separated by a ground plane. Noise generated through the inductor can interfere with radio operation.





## Antenna ESD Considerations

The antenna pin is a particularly sensitive node for electro-static discharge (ESD) since it must detect small, high-frequency signals. ESD damage to the LTP5900 may result in decreased receive or transmit performance, or other system failure. Many applications for the LTP5900 have an exposed antenna that provides an entry point for ESD events. Proper consideration of antenna design as well as antenna protection can substantially improve ESD robustness in harsh environments.

A radome (protective covering) made of highly resistive material may be used to prevent direct contact with the antenna and/or dissipate charge. To avoid ESD events caused by triboelectric charging generated by wind passing over the antenna in dry climates, the radome design should consider bulk and surface resistivity as well as the size of the gap between the antenna metal and the interior of the radome.

In general, DC-grounded antennas (in which the antenna and ground have a DC short) provide superior protection to ESD events. DC-grounded antennas are highly recommended in harsh environments. Additionally, a DC path-to-earth ground should be provided whenever possible to help bleed off accumulated charge from the antenna as well as leak charge from the radome.

While these general guidelines should improve robustness to ESD events, individual implementations may have unique factors that complicate ESD protection. Upon request, Linear Technology can provide contact information for an external consultant able to perform a review for ESD and other system considerations.

## **Voltage Supervision and Reset**

The LTP5900 includes a power-on reset to safely set its own state during power up, and includes a brown-out circuit that immediately halts flash erase cycles and interrupts flash write cycles at the next 32-bit boundary, generating an interrupt to the CPU and maintaining state for the CPU to correct should the power supply return to normal operating levels. In the interest of avoiding flash corruption, it is not considered best practice to connect the LTP5900 RST lead to a voltage supervisor or to asynchronously assert RST without previously suspending network and flash activity.

#### **Design for Manufacture**

The schematic shown in Figure 1 shows a header, J3, intended to provide an interface to allow programming the LTP5900. A mechanism to program the LTP5900 is prudent for development. The header, Molex 87831-1020, provides connectivity through a cable to the DC9010 USB serial programmer described in the Eterna Serial Programmer Guide. The programmer software provided for controlling the programmer allows users to program and verify pages in flash, and optionally the entire flash contents. Note that the programmer provided by Dust Networks has a limited capability for supplying current to the DUT.







Figure 1 Programming Header Example Schematic





#### Trademarks

The Dust Networks logo, Dust, Dust Networks, and SmartMesh are registered trademarks of Dust Networks, Inc. LTP5900 is a trademark of Dust Networks. All third-party brand and product names are the trademarks of their respective owners and are used solely for informational purposes.

#### Copyright

This documentation is protected by United States and international copyright and other intellectual and industrial property laws. It is solely owned by Dust Networks, Inc. and its licensors and is distributed under a restrictive license. This product, or any portion thereof, may not be used, copied, modified, reverse assembled, reverse compiled, reverse engineered, distributed, or redistributed in any form by any means without the prior written authorization of Dust Networks, Inc.

RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g) (2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015 (b)(6/95) and DFAR 227.7202-3(a), and any and all similar and successor legislation and regulation.

#### Disclaimer

This documentation is provided "as is" without warranty of any kind, either expressed or implied, including but not limited to, the implied warranties of merchantability or fitness for a particular purpose.

This documentation might include technical inaccuracies or other errors. Corrections and improvements might be incorporated in new versions of the documentation.

Dust Networks does not assume any liability arising out of the application or use of any products or services and specifically disclaims any and all liability, including without limitation consequential or incidental damages.

Dust Networks products are not designed for use in life support appliances, devices, or other systems where malfunction can reasonably be expected to result in significant personal injury to the user, or as a critical component in any life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness. Dust Networks customers using or selling these products for use in such applications do so at their own risk and agree to fully indemnify and hold Dust Networks and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Dust Networks was negligent regarding the design or manufacture of its products.

Dust Networks reserves the right to make corrections, modifications, enhancements, improvements, and other changes to its products or services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to Dust Network's terms and conditions of sale supplied at the time of order acknowledgment or sale.

Dust Networks does not warrant or represent that any license, either express or implied, is granted under any Dust Networks patent right, copyright, mask work right, or other Dust Networks intellectual property right relating to any combination, machine, or process in which Dust Networks products or services are used. Information published by Dust Networks regarding third-party products or services does not constitute a license from Dust Networks to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from Dust Networks under the patents or other intellectual property of Dust Networks.

© Dust Networks, Inc. 2011, 2012. All Rights Reserved.

Document Number:	040-0111 LTP5900 Integration Guide

Last Revised:

October 24, 2013

Document Status	Product Status	Definition
Advanced Information	Planned or under development	This document contains the design specifications for product development. Dust Networks reserves the right to change specifications in any manner without notice.
Preliminary	Engineering samples and pre-production prototypes	This document contains preliminary data; supplementary data will be published at a later date. Dust Networks reserves the right to make changes at any time without notice in order to improve design and supply the best possible product. The product is not fully qualified at this point.
No identification noted	Full Production	This document contains the final specifications. Dust Networks reserves the right to make changes at any time without notice in order to improve design and supply the best possible product.
Obsolete	Not in production	This document contains specifications for a product that has been discontinued by Dust Networks. The document is printed for reference information only.