



BRNS-series



Feature

Small size and high efficiency non-isolated DC-DC converter. Wide input voltage 3.0V to 14.4V. Adjustment of the gain control depending on external capacitor is unnecessary. Built-in remote ON/OFF,Power good,Frequency synchronization. Built-in overcurrent and thermal protection (auto recovery type) functions.

CE marking

Low Voltage Directive RoHS Directive

UKCA marking

Electrical Equipment Safety Regulations RoHS Regulations

Safety agency approvals

UL60950-1, C-UL, EN62368-1



CD\$EL DC-DC Converters POL Type			Ordering information				
	BRN	IS	BRN S 20	•			
RoHS	<image/>	BRNS12 BB99999CR	BRNS20 S9999999CR	 Series name Single output Output current 6:6A 12:12A 20:20A Optional R: Positive logic remote on/off 1: No clock output for frequency synchronization Y1: Suitable control for external capacitor over 470 µ F 			
MODEL		BRNS6	BRNS12	BRNS20			
-	JT CURRENT[A]	6.0	12.0	20.0			
DC OUTPUT		0.6 - 5.5	12.0	20.0			
	CATIONS	1					
	MODEL	BRNS6	BRNS12	BRNS20			
	VOLTAGE[V]	DC3.0 - 14.4					
INPUT	CURRENT[A] *1	0.70 typ	1.40 typ	2.30 typ			
	EFFICIENCY[%] *1	86 typ	86 typ	87 typ			
	VOLTAGE[V] *2	0.6 - 5.5	0.6 - 5.5	0.6 - 5.5			
	CURRENT[A]	6	12	20			
	LINE REGULATION1[mV] Vo≦1.8V	10					
	LINE REGULATION2[%Vo] Vo>1.8V	0.5					
	LOAD REGULATION1[mV] Vo≦1.8V	10					
OUTPUT	LOAD REGULATION2[%Vo] Vo>1.8V	0.5					
	OUTPUT VOLTAGE SETTING [%Vo]	±1.0					
	RIPPLE[mVp-p] *3	3 25					
	RIPPLE NOISE[mVp-p] *3	3 50					
	DRIFT[%Vo] *4	±0.5					
	START-UP TIME[ms]	4.5 typ					
		Adjustable by external resistor					
	ADJUSTMENT RANGE	0.6 - 5.5					
	OUTPUT VOLTAGE REGULATION [%Vo]*5	±3.0					
PROTECTION	OVERCURRENT PROTECTION	Works over 105% of rating (auto reco	overy type)				
PROTECTION CIRCUIT AND OTHERS	REMOTE SENSING	Available (+S only) Available					
	REMOTE ON/OFF	Available Negative logic L:ON, H:OFF					
ISOLATION	INPUT-OUTPUT	non-isolated					
	OPERATING TEMP., HUMID. AND ALTITUDE	-40 to +85°C, 20-95%RH (Non condensing) (Refer to "Derating") 3,000m (10,000feet) max					
ENVIRONMENT	STORAGE TEMP., HUMID. AND ALTITUDE	-40 to +100℃, 20-95%RH (Non cond	0,000				
		10 FELL- 10 0m/22/FO) 0m/mutas ma	riad 60minutes each along V. V and 7	t a cita			

*1 At rated input (DC12V) and rated output (1.2V) Ta=25°C. *2

Output voltage is adjusted to the minimum when TRM is opend. *3

Ripple and ripple noise is measured by using measuring board with ceramic capacitor at 25mm from output pin. At rated input (DC12V) and rated output (1.2V).

*4 Drift is the change in DC output for an eight hour period after a halt - hour warm - up at 25 C, with the input voltage nois.
 *5 Output voltage setting is added line regulation and load regulation and temperature regulation used resistance of the 0.5% tolerance.



External view



COŞEL | BRNS-series

Pin Configuration

BRNS6/12

	3		2	
4			1	16
5	13			1
14			1	1
6	15	1	8	9
	*BOTTOM VIEW			

BRNS20



			T				
	Pin No.						
BR 6/		BRNS 20	Pin Connection	Function			
	1		RC	Remote ON/OFF			
	2		+VIN	+DC input			
3	B)	4	GND	GND(-DC input, -DC output)			
(4	4 6		+VOUT	+DC output			
(5	5 7		+S	+Remote sensing			
(6	6	5	TRM	Adjustment of output voltage			
0	Ď	14	SGND	Signal GND			
(8	3)	1)	CLK(NC)	Clock output			
Q	9 3		SEQ	Control of Start up time and turn			
1	10 9		PGOOD	Power good			
Œ	D	10	SYNC	Input for frequency synchronization			
1	2)	8	-S	NC : BRNS6/12 -Remote sensing : BRNS20			
1	3)	1	NC	NC			
(4)	(13)	NC	NC			
1	5)	(12)	NC	NC			
1	6)	(16)	NC	NC			
Ĩ	1) 15		NC	NC			

Implementation · Mounting Method

Mounting method

The unit can be mounted in any direction. When two or more power supplies are used side by side, position them with proper intervals to allow enough air ventilation. The temperature around each power supply should not exceed the temperature range shown in "Derating".

Automatic Mounting

To mount BRNS series automatically, use the coil area near the center of the PCB as an adsorption point. Please see the External View for details of the adsorption point.

Soldering

- Right figure shows condition for reflow of BRNS series. Please make sure that the temperature of board's pattern near by +VOUT and GND terminal.
- While soldering, having vibration or impact on the unit should be avoided, because of solder melting.
- Please do not do the implementation except the reflow.
- Because some parts drops, please do not do reflow of the back side.



BRNS-series | CO\$EL



Derating

Make sure the temperatures measurement locations shown from Instruction Manual 8 are on or under the derating curve in right figure. Ambient temperature must be kept at 85°C or under.



Instruction Manual

◆ It is neccessary to read the "Instruction Manual" and "Before using our product" before you use our product.

Instruction Manual Before using our product

https://www.cosel.co.jp/redirect/catalog/en/BRNS/ https://en.cosel.co.jp/technical/caution/index.html





Basic Characteristics Data

Model	Circuit method	Switching frequency [kHz] (reference)		Inrush current protection	PCB/Pattern		Series/Parailel operation		
					Material	Single sided	Double sided	Series operation	Parailel operation
BRNS6	Buck Converter	600	*1	-	glass fabric base,epoxy resin	-	Multilayer	-	-
BRNS12	Buck Converter	600	*1	-	glass fabric base,epoxy resin	-	Multilayer	-	-
BRNS20	Buck Converter	600	*1	-	glass fabric base,epoxy resin	-	Multilayer	-	-

*1 Refer to Specification.