

STRUCTURE Silicon Monolithic Integrated Circuit

NAME OF PRODUCT DC-AC Inverter Control IC

TYPE BD9885FV

FUNCTION • 2ch control with Half-bridge

- · Lamp current and voltage sense feed back control
- Sequencing easily achieved with Soft Start Control
- Short circuit protection with Timer Latch
- · Under Voltage Lock Out
- · Short circuit protection with over voltage
- Mode-selectable the operating or stand-by mode by stand-by pin
- Synchronous operating the other BD9885FV IC's
- BURST mode controlled by PWM and DC input
- · Variable to standard Voltage for Lamp current Feed back

OAbsolute Maximum Ratings ($Ta = 25^{\circ}C$)

Parameter	Symbol	Limits	Unit
Supply Voltage	Vcc	15	V
Operating Temperature Range	Topr	-40∼+90	°C
Storage Temperature Range	Tstg	-55 ~ +125	°C
Power Dissipation	Pd	850*	mW
Maximum Junction Temperature	Tjmax	+125	°C

^{*}Pd derated at 8.5mW/°C for temperature above Ta = 25°C (When mounted on a PCB 70.0mm×70.0mm×1.6mm)

ORecommended operating condition

Parameter	Symbol	Limits	Unit
Supply voltage	Vcc	5. 0~14. 0	٧
CT oscillation frequency	fcT	20~150	kHz
BCT oscillation frequency	fвст	0.05~0.50	kHz




○電気的特性 (Ta=25°C, VCC=7V)

COMPATE DEVICE) COLUMN	Parameter	Symbol		Limits	1	Unit	Conditions
Description current	((WHOLE DEVICE))		MIN.	TYP.	MAX.		
Stand-by voltage detact voltage Vorf 2		lcc1	T -	11 0	17.0	mΔ	CT=0_5V
							01-0.01
(ISFAM BY CONTROL)) Stand-by voltage H		.002		_		μ	
(ISFAM BY CONTROL)) Stand-by voltage H	FB over voltage detect voltage	Vovf	2. 20	2. 40	2. 60	٧	
Stand-by voltage Stand-by voltage Stand-by hysteresis 29kt 0.10 0.25 0.40 V		1	•				•
Stand-by Investrens	Stand-by voltage H	VstH	1.4	_	VCC	٧	System ON
C(THER LATOH) Timer Latch outrage Vop 1.8 2.0 2.2 V	Stand-by voltage L	VstL	-0. 3	_	0. 5	٧	System OFF
Timer Latch voltage	Stand-by hysteresis	⊿Vst	0. 10	0. 25	0. 40	٧	
Timer Latch current							
(IOSC BLOOK)) 050 constant current		· · · · · · · · · · · · · · · · · · ·					
DSC Constant current	limer Latch current	lcp	0.5	1. 0	1.5	μA	
SSC Max voltage	((OSC BLOCK))						
SSC Nin voltage Voscl. 0.3 0.5 0.7 V fcr=60kHz	OSC constant current	Іст	1.35/RT	1. 5/RT	1. 65/RT	Α	
MAXDUTY	OSC Max voltage	VoscH	1.8	2. 0	2. 2	٧	fct=60kHz
MAX DUTY MAX DUTY MAX DUTY 44	OSC Min voltage	VoscL	0.3	0. 5	0. 7	٧	fct=60kHz
Soft start current Iss 1.0 2.0 3.0 μA			44	46. 5	49	%	
SECONDP detect Voltage							
SS CMM detect voltage							
SRT ON resistance	-						
(UMLO BLOCK) Operating voltage	SRT ON resistance						
Lock out voltage Viviol 3.900			<u>.</u>				<u> </u>
Lock out voltage Viviol 3.900	Operating voltage	Vuv I oH	4. 100	4. 300	4. 500	V	
Lock out voltage (External UVLO)	Lock out voltage	Vuv I oL	3. 900	4. 100	4. 300	V	
(FEED BACK BLOCK) IS threshold voltage Vis1 1.220 1.250 1.280 V VREF=Open	Operating voltage (External UVLO)	Vuv I o 1	1. 900	2. 000			
Sthreshold voltage1	Lock out voltage (External UVLO)	Vuv I o 2	2. 100	2. 200	2. 300	V	
Sthreshold voltage Vis2 - Vref2 - V VREF=Applying Voltage	((FEED BACK BLOCK))						
String Visual	IS threshold voltage1	Vis1	1. 220	1. 250	1. 280	V	
Source current Sou	IS threshold voltage2	Vis2	-	Vref2	-	٧	
S source current 2	VS threshold voltage	Vvs	1. 220	1. 250	1. 280	٧	
VS Source current Ivs - - 1.0	IS source current 1	lis1	_	_	1.5	μA	DUTY=2. OV
((OUTPUT BLOCK)) Peh output voltage H VoutPH VCC-0.3 VCC-0.1 — V Neh output voltage H VoutNH VCC-0.3 VCC-0.1 — V Peh output voltage L VoutPL — 0.1 0.3 V Neh output sink resistance RsinkP — 8 16 Ω Isink = 10mA Peh output source resistance RsourceP — 10 20 Ω Isource = 10mA Neh output sink resistance RsourceN — 10 20 Ω Isource = 10mA Neh output sink resistance RsourceN — 10 20 Ω Isource = 10mA Neh output sink resistance RsourceN — 10 20 Ω Isource = 10mA Neh output sink resistance RsourceN — 10 20 Ω Isource = 10mA Neh output sink resistance RsourceN — 10 20 Ω Isource = 10mA (EBOSE) MSOMOBE BLOCK) No	IS source current 2	lis2	13. 0	20. 0	27. 0	μA	DUTY=OV、IS=0.5V
Peh output voltage H VoutPH VCC-0.3 VCC-0.1 V	VS source current	lvs	_	_	1. 0	μΑ	
Peh output voltage H VoutPH VCC-0.3 VCC-0.1 V	((OUTPUT BLOCK))			l	1		
Noch output voltage H VoutNH VCC-0.3 VCC-0.1 V VCC-0 output voltage L VoutPL 0.1 0.3 V VCC-0.1 VCC-0.3 VCC-0.1 V VCC-0.3 VCC-0.1 VCC		VoutPH	VCC-0 3	VCC-0 1	_	V	
Peh output voltage L VoutPL - 0.1 0.3 V			+		ļ	<u> </u>	
Note output voltage L VoutNL - 0.1 0.3 V			-				
Pch output sink resistance RsinkP							
Poh output source resistance RsourceP — 10 20 Ω Isource = 10mA Nch output sink resistance RsinkN — 8 16 Ω Isink = 10mA Nch output source resistance RsourceN — 10 20 Ω Isource = 10mA ((BURST MODE BLOCK)) SECONDAY NODE BLOCK) Word 1.94 2.0 2.06 V fBcct=0.2kHz BOSC Max voltage VburL 0.4 0.5 0.6 V fBcct=0.2kHz BOSC constant current IBCT 1.35/BRT 1.5/BRT 1.65/BRT A ((REG BLOCK)) REG output voltage VREG 3.038 3.100 3.162 V REG output voltage Vref1 1.220 1.250 1.280 V VREF=Open VREF voltage Vref2 0.60 — 1.60 V VREF=Applying Voltage ((COMP BLOCK)) Over voltage detect VCOMPH 2.20 2.5 2.80 V Under voltage detect	Pch output sink resistance						Isink = 10mA
Note output sink resistance RsinkN - 8		RsourceP	_	10		1	
((BURST MODE BLOCK)) BOSC Max voltage	Nch output sink resistance	RsinkN	_	8	16	Ω	Isink = 10mA
BOSC Max voltage	Nch output source resistance	RsourceN	_	10	20	Ω	Isource = 10mA
BOSC Min Voltage	((BURST MODE BLOCK))						
BOSC constant current Bot 1.35/BRT 1.5/BRT 1.65/BRT A	BOSC Max voltage		1. 94	2. 0			
((REG BLOCK)) REG output voltage VREG 3.038 3.100 3.162 V REG source current IREG 5.0 — — mA VREF voltage Vref1 1.220 1.250 1.280 V VREF=Open VREF input voltage range Vref2 0.60 — 1.60 V VREF=Applying Voltage ((COMP BLOCK)) Over voltage detect VCOMPH 2.20 2.5 2.80 V Under voltage detect VCOMPL 0.590 0.640 0.690 V ((PROTECT CLOCK)) Normal output voltage VPH 2.9 3.1 3.3 V	BOSC Min Voltage	VburL	0.4	0. 5	0.6	٧	fBCT=0. 2kHz
REG output voltage VREG 3.038 3.100 3.162 V REG source current IREG 5.0 -	BOSC constant current	Івст	1. 35/BRT	1. 5/BRT	1. 65/BRT	Α	
REG output voltage VREG 3.038 3.100 3.162 V REG source current IREG 5.0 -	((REG BLOCK))		<u>.</u>				<u> </u>
REG source current IREG 5.0	REG output voltage	VREG	3. 038	3. 100	3. 162	٧	
VREF voltage Vref1 1.220 1.250 1.280 V VREF=Open VREF input voltage range Vref2 0.60 - 1.60 V VREF=Applying Voltage ((COMP BLOCK)) Over voltage detect VCOMPH 2.20 2.5 2.80 V Under voltage detect VCOMPL 0.590 0.640 0.690 V ((PROTECT CLOCK)) Normal output voltage VPH 2.9 3.1 3.3 V	REG source current			_	_	mA	
VREF input voltage range Vref2 0.60 - 1.60 V VREF=Applying Voltage ((COMP BLOCK)) Over voltage detect VCOMPH 2.20 2.5 2.80 V Under voltage detect VCOMPL 0.590 0.640 0.690 V ((PROTECT CLOCK)) Normal output voltage VPH 2.9 3.1 3.3 V				1, 250	1, 280		VREF=Open
VCOMP BLOCK) Over voltage detect VCOMPH 2.20 2.5 2.80 V Under voltage detect VCOMPL 0.590 0.640 0.690 V ((PROTECT CLOCK)) Normal output voltage VPH 2.9 3.1 3.3 V							VREF=Applying
Over voltage detect VCOMPH 2.20 2.5 2.80 V Under voltage detect VCOMPL 0.590 0.640 0.690 V ((PROTECT CLOCK)) Normal output voltage VPH 2.9 3.1 3.3 V	((COMP BLOCK))	l	ı	I	ı	1	Forcago
Under voltage detect VCOMPL 0.590 0.640 0.690 V ((PROTECT CLOCK)) Normal output voltage VPH 2.9 3.1 3.3 V		VCOMPH	2, 20	2. 5	2. 80	٧	
((PROTECT CLOCK)) Normal output voltage VPH 2.9 3.1 3.3 V							
Normal output voltage VPH 2.9 3.1 3.3 V		130mi L	0.000	0.040	0.000		
		VPH	2.9	3 1	3 3	V	


(This product is not designed for normal operation with in a radio active environment.)



OPackage Dimensions



OBlock Diagram



OPin Description

Pin No.	Pin Name	Function
1	DUTY	Control PWM mode and BURST mode
2	BRT	External resistor from BRT to GND for adjusting the BURST triangle oscillator
3	ВСТ	External capacitor from BCT to GND for adjusting the BURST triangle oscillator
4	RT	External resistor from SRT to RT for adjusting the triangle oscillator
5	SRT	External resistor from SRT to RT for adjusting the triangle oscillator
6	СТ	External capacitor from CT to GND for adjusting the triangle oscillator
7	GND	GROUND
8	FB1	Error amplifier output①
9	IS1	Error amplifier input①
10	VS1	Error amplifier input②
11	FB2	Error amplifier output②
12	182	Error amplifier input3
13	VS2	Error amplifier input④
14	VREF	Reference voltage for ISNECE error amplifier
15	FAIL	Protect clock output
16	STB	Stand-by switch
17	COMP1	Under, over voltage detect for 1ch
18	COMP2	Under, over voltage detect for 2ch
19	UVL0	External Under Voltage Lock OUT
20	REG	Internal regulator output
21	SS	External capacitor from SS to GND for Soft Start Control
22	SCP	External capacitor from SCP to GND for Timer Latch
23	P2	FET driver for 2ch
24	N2	FET driver for 2ch
25	PGND	Ground for FET drivers
26	N1	FET driver for 1ch
27	P1	FET driver for 1ch
28	VCC	Supply voltage input



ONOTE FOR USE

- 1. When designing the external circuit, including adequate margins for variation between external devices and the IC. Use adequate margins for steady state and transient characteristics.
- 2. Recommended Operating Range

The circuit functionality is guaranteed within of ambient temperature operation range as long as it is within recommended operating range. The standard electrical characteristic values cannot be guaranteed at other voltages in the operating ranges, however, the variation will be small.

3. Mounting Failures

Mounting failures, such as misdirection or miscounts, may harm the device.

4. Electromagnetic Fields

A strong electromagnetic field may cause the IC to malfunction.

- 5. The GND pin should be the location within $\pm 0.3V$ compared with the PGND pin
- 6. BD9885FV has the short circuit protection with Thermal Shut Down System. When STB or Vcc pin re-supplied, They enables to cancel the latch. If It rise the temperature of the chip more than 170°C (TYP), It make the external FET OFF
- 7. Absolute maximum ratings are those values that, if exceeded, may cause the life of a device to become significantly shortened.
 Moreover, the exact failure mode caused by short or open is not defined. Physical countermeasures, such as a fuse, need to be considered when using a device beyond its maximum ratings.
- 8. About the external FET, the parasitic Capacitor may cause the gate voltage to change, when the drain voltage is switching.

 Make sure to leave adequate margin for this IC variation.
- 9. On operating Slow Start Control (SS is less than 2.2V), It does not operate Timer Latch.
- 1 O. By STB voltage, BD9885FV is changed to 2 states. Therefore, do not input STB pin voltage between one state and the other state $(0.5 \sim 1.4 \text{V})$.
- 1 1. The pin connected a connector need to connect to the resistor for electrical surge destruction.
- 1 2. This IC is a monolithic IC which (as shown is Fig-1)has P⁺ substrate and between the various pins. A P-N junction is formed from this P layer of each pin. For example, the relation between each potential is as follows,
 - O (When GND > PinB and GND > PinA, the P-N junction operates as a parasitic diode.)
 - O(When PinB > GND > PinA, the P-N junction operates as a parasitic transistor.)

Parasitic diodes can occur inevitably in the structure of the IC. The operation of parasitic diodes can result in mutual interference among circuits as well as operation faults and physical damage. Accordingly you must not use methods by which parasitic diodes operate, such as applying a voltage that is lower than the GND(P substrate) voltage to an input pin.




Fig-1 Simplified structure of a Bipolar IC

Notes

No copying or reproduction of this document, in part or in whole, is permitted without the consent of ROHM Co.,Ltd.

The content specified herein is subject to change for improvement without notice.

The content specified herein is for the purpose of introducing ROHM's products (hereinafter "Products"). If you wish to use any such Product, please be sure to refer to the specifications, which can be obtained from ROHM upon request.

Examples of application circuits, circuit constants and any other information contained herein illustrate the standard usage and operations of the Products. The peripheral conditions must be taken into account when designing circuits for mass production.

Great care was taken in ensuring the accuracy of the information specified in this document. However, should you incur any damage arising from any inaccuracy or misprint of such information, ROHM shall bear no responsibility for such damage.

The technical information specified herein is intended only to show the typical functions of and examples of application circuits for the Products. ROHM does not grant you, explicitly or implicitly, any license to use or exercise intellectual property or other rights held by ROHM and other parties. ROHM shall bear no responsibility whatsoever for any dispute arising from the use of such technical information.

The Products specified in this document are intended to be used with general-use electronic equipment or devices (such as audio visual equipment, office-automation equipment, communication devices, electronic appliances and amusement devices).

The Products specified in this document are not designed to be radiation tolerant.

While ROHM always makes efforts to enhance the quality and reliability of its Products, a Product may fail or malfunction for a variety of reasons.

Please be sure to implement in your equipment using the Products safety measures to guard against the possibility of physical injury, fire or any other damage caused in the event of the failure of any Product, such as derating, redundancy, fire control and fail-safe designs. ROHM shall bear no responsibility whatsoever for your use of any Product outside of the prescribed scope or not in accordance with the instruction manual.

The Products are not designed or manufactured to be used with any equipment, device or system which requires an extremely high level of reliability the failure or malfunction of which may result in a direct threat to human life or create a risk of human injury (such as a medical instrument, transportation equipment, aerospace machinery, nuclear-reactor controller, fuel-controller or other safety device). ROHM shall bear no responsibility in any way for use of any of the Products for the above special purposes. If a Product is intended to be used for any such special purpose, please contact a ROHM sales representative before purchasing.

If you intend to export or ship overseas any Product or technology specified herein that may be controlled under the Foreign Exchange and the Foreign Trade Law, you will be required to obtain a license or permit under the Law.



Thank you for your accessing to ROHM product informations.

More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

http://www.rohm.com/contact/